

BATTERY INSTALLATION


- To release battery cover on bottom, turn battery cover (Fig. 1) counter-clockwise and pull.
 - Install (2) AA batteries. Be sure batteries are inserted in the proper direction.
 - To replace battery cover, line up bottom cap with taper base (Fig. 2), push and turn battery cover clockwise until securely in place.
- Note: Alkaline batteries are recommended for maximum battery life.

CANDLE OPERATION

- To use ON/OFF operation: Press the power button on the bottom of the candle to operate.
- To use the 5 hour TIMER operation: At the desired 'ON' time, press and hold the power button until the candle blinks once. The timer is now activated and will automatically turn on at the set time everyday and turn off after 5 hours.



realite



CANDLE MAINTENANCE

- Clean with a soft, dry cloth.
- If needed, use a damp cloth and mild household soap.

CAUTION

- Flaming motion (shifting) effect design is delicate in nature. Touching the flame piece could cause improper performance.
- This product is not water proof. Place this product away from damp surroundings and do not submerge in water.
- Failure to insert batteries correctly may shorten the life of the batteries or cause batteries to leak, which may damage the candle.
- Do not mix old and new batteries. Do not mix alkaline, carbon zinc, rechargeable nickel cadmium or rechargeable nickel metal hydride batteries.
- Do not dispose of batteries in fire. Recycle or dispose of batteries as per battery manufacturer recommendations.

Distributed exclusively by **abbott**
Scan the QR for more product information

www.reallite.ca



里阳
Liown



INSTALLATION DE PILES


- Pour enlever le couvercle des piles (Fig. 1) en bas de la bougie, tourner le couvercle vers le sens antihoraire.
- Installer (2) piles AA. Se rassurer que les piles soient insérées dans la bonne direction.
- Pour replacer le couvercle des piles, aligne le couvercle avec la base de la bougie (Fig. 2), pousser et tourner le couvercle des piles dans le sens horaire jusqu'à ce qu'il est sécuritaire en place.
Note : Les piles alcalines sont recommandées pour un fonctionnement maximal des piles.

FONCTIONNEMENT DE LA BOUGIE

- Pour utiliser le fonctionnement ON/OFF: Pesez le bouton en bas de la bougie.
- Pour utiliser le fonctionnement de minuterie à 5 heures : Au temps désiré, pesez et maintenez le bouton « ON/OFF » jusqu'à ce que le bougie clignote une fois. La minuterie est maintenant activé et va s'allumer automatiquement au moment programmé chaque jour et va s'éteindre après 5 heures.



realite



ENTRETIEN DE LA BOUGIE

- Laver avec un chiffon sèche et propre.
- Au besoin, utiliser un chiffon humide avec du savon doux.

AVERTISSEMENT

- Le modèle du mouvement de la flamme est délicat et toucher la partie de la flamme pourrait causer une performance fautive.
- Ce produit n'est pas imperméable. Placer ce produit hors des espaces humides et ne pas submerger dans l'eau.
- Une mauvaise installation des piles pourrait raccourcir leur vie ou causer les piles à couler, ce qui pourrait endommager la bougie.
- Ne pas combiner des nouvelles piles avec des vieilles. Ne pas combiner des piles d'alcalin, de carbone-zinc, des accumulateurs de cadmium, ou des accumulateurs de nickel-hydrure métallique.
- Ne pas jeter les piles dans le feu. Recycler ou se débarrasser des piles tel que recommandé par le fabricant.

Distribué exclusivement par **abbott**
Scannez le QR pour plus d'information sur le produit.

www.reallite.ca

里阳
Liown®

